


### Ziza® Interior Lighting Package Installation Procedures



Part Number ES2207808

for Audi B5 A4

(sedan or Avant)

(1996-2001)

Audi B5 S4

(2000-2002)

Proper service and repair procedures are vital to the safe, reliable operation of all motor vehicles as well as the personal safety of those performing the repairs. Standard safety procedures and precautions (including use of safety goggles and proper tools and equipment) should be followed at all times to eliminate the possibility of personal injury or improper service which could damage the vehicle or compromise its safety.

Although this material has been prepared with the intent to provide reliable information, no warranty (express or implied) is made as to its accuracy or completeness. Neither is any liability assumed for loss or damage resulting from reliance on this material. SPECIFICALLY, NO WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR ANY OTHER WARRANTY IS MADE OR TO BE IMPLIED WITH RESPECT TO THIS MATERIAL. In no event will ECS Tuning, Incorporated or its affiliates be liable for any damages, direct or indirect, consequential or compensatory, arising out of the use of this material.



#### Fits Audi B5 A4 sedan or Avant/S4



This tutorial explains how to install the LEDs in your Ziza Interior Lighting Kit.



Make the job easier and prevent damage to headliners and other interior trim with ECS Tuning Trim and Molding Removal Tool Sets: <u>ES2500877</u> and <u>ES517779</u>.

Page - 2

ES2207808



#### Fits Audi B5 A4 sedan or Avant/S4

#### What are LEDs?

LEDs are Light Emitting Diodes, solid state devices that emit light when connected to electrical current. They have no moving parts or wire filaments to burn out. They emit a whiter light, run cooler, and last longer that the incandescent (filament style bulbs) we are replacing in this tutorial.

Unlike filament bulbs, LEDs are polarity sensitive. They have plus and minus (positive and negative) electrical terminals that must match the polarity of the applied voltage. Installing the bulbs "backwards" in the light bulb sockets (with reversed polarity) will not harm them, but they will not light. Flipping the bulb 180 degrees in the electrical connector cures this problem.

#### **Bulb Types**

This kit includes three bulb types, classified by their general shape.

FESTOON - Conventional incandescent festoon bulbs have a shape and general appearance that is similar to a glass fuse.

Metal caps attached to both ends of a glass tube are festoon sealed to the tube and attached to the bulb filament. End caps mount the bulb in its holder and also conduct electrical current.

LED festoon lights have the same pointed end caps, but are attached to a bank of LEDs instead of a filament tube.

WEDGE - Wedge style bulbs get their name from the shape of the bulb base. The tapered end of the bulb "wedges" into the bulb socket.


LED wedge lights fit the bulb socket like a filament bulb, but are polarity sensitive.




wedge







While these are also polarity sensitive, the socket design automatically orients the bulb, ensuring correct polarity.



Address: 1000 Seville Road, Wadsworth, OH 44281


Phone: 1.800.924.5172



#### Fits Audi B5 A4 sedan or Avant/S4

#### **General Tips**

- When prying down on the assemblies to remove them, pry on the notched end of
  the lens. Insert the narrow tool tip **between** the lens plastic and any metal collar
  used to reinforce the lens mounting hole. Push in on the retaining clip first to
  compress and release it. Then pry down.
- The spring bulb retainer is also the circuit conductor. If necessary, gently bend
  the metal retainer so it holds the bulb tight. This will help prevent intermittent or
  flickering LED operation caused by a loose connection.
- Install the bulbs with the LEDs facing toward the lens.



Page - 4



#### Fits Audi B5 A4 sedan or Avant/S4

### **Ziza Interior Lighting Kit Locations** Make Audi Model\_\_\_B5 S4 and B5 A4\_\_\_(and Avant)\_\_\_\_\_ Kit Part Number\_\_\_\_\_ES2207808 \_\_\_\_\_ cargo light (Avant) 36mm festoon (qty 2) trunk ES2515359 36mm festoon ES2515359 optional trunk 36mm festoon ES2515359 rear dome bayonet qty (2) ES2515347 footwell glove box wedge (qty 2) 36mm festoon ES2526289 ES2515359 sun visor 36mm festoon (qty 2) ES2515359 front dome 42mm festoon (qty 2) ES2515360 bayonet (qty 2) ES2515347

ES2207808



#### Fits Audi B5 A4 sedan or Avant/S4

# Front Dome and Vanity LED Installation



#### Front Dome - Step 1

Use a non-marring plastic trim removal tool to pry the lens from the front dome light console.



#### Front Dome - Step 2

The original festoon filament bulbs are covered with plastic diffusers.

Push gently on the front leg of each diffuser to release it (toward the arrows), and then remove the diffuser and festoon filament bulb beneath it.



Page - 6

ES2207808



#### Fits Audi B5 A4 sedan or Avant/S4

#### Front Dome - Step 3

Install one new 42mm LED in each bulb retainer, as shown. Test them; flip them end-for-end if they do not illuminate when first tested.



#### Front Dome - Step 4

Snap the plastic diffusers back in place. Don't replace the main lens cover yet.



#### Front Dome - Step 5

Pry on the front dome light console with the nonmar plastic trim tool. Work around the edges until all the plastic clips release.

Drop the cover.



Page - 7

ES2207808



#### Fits Audi B5 A4 sedan or Avant/S4

#### Front Dome - Step 6

Remove the old bayonet bulbs. Twist and pull.

Push and twist to insert one bayonet style LED in each front socket.



#### Front Dome - Step 7

Test all lights. Snap the lens and front cover in place.



#### Vanity Mirror - Step 1

Insert the tip of the non-marring pry tool into the notched end of the light assembly. Push in to compress the retaining tab while prying down to release the light assembly from the headliner.

- Pull the assembly down. Remove the snap-on heat shield.
- Insert the new festoon LED in the light assembly and replace the assembly.
- Repeat on the opposite side of the car.



Page - 8

ES2207808



#### Fits Audi B5 A4 sedan or Avant/S4

# Rear Dome and Trunk Light LEDs



#### **Rear Dome - Step 1**

Using the non-mar pry tool, push in to release the retaining clips while prying down to free the light assembly from the headliner.




#### Rear Dome - Step 2

Remove the filament style bayonet bulbs (quantity 2) and replace them with LED bayonet bulbs.

These are push-and-twist to remove and install.

Test bulb operation, then reinstall the rear dome light assembly in the headliner.



Page - 9

ES2207808



#### Fits Audi B5 A4 sedan or Avant/S4

#### Trunk - Step 1

Pry out the light assembly from the right side inner panel inside the trunk. Replace the filament style festoon with a 36mm LED. Install the LED with the chips facing the lens.



#### Trunk - Step 2

Pry out the light assembly from the top panel inside the trunk.



#### Trunk - Step 3

Pry off the metal shield covering the light and its electrical connections.

- Replace the original festoon filament bulb with a 36mm LED festoon.
- If the LED does not work when first installed, flip it end-for-end and reinstall it.
- Replace the metal shield and reinstall the light assembly.



ES2207808



Fits Audi B5 A4 sedan or Avant/S4

# Glove Box and Footwell LEDs



#### **Glove Box**

Pry down the festoon light assembly from the top of the glove box liner.

Replace the festoon filament bulb with a 36mm LED festoon.




#### **Footwells**

Both left and right front footwells have light fixtures with wedge base bulb holders. Pry them loose and drop them down.

Remove the old filament bulbs; install wedge base LEDs from the kit.

Wedge bulbs are polarity sensitive. If they do not light when installed, flip them over, reinsert, and test again.



Page - 11

ES2207808



#### **Avant Only**

#### Fits Audi B5 A4 sedan or Avant/S4

#### **Special for Avant Owners**

Avant owners have a special light assembly located in the rear cargo area.

Open the lift gate. Using a flat tip trim removal tool, pry at the edge of the lens cover, as shown.



Remove the old glass filament festoon bulbs and replace them with 36mm festoon LED arrays.

Snap the lens cover back in place.



This concludes the installation of the Ziza Interior Light Kit.



Make the job easier and prevent damage to headliners and other interior trim with ECS Tuning Trim and Molding Removal Tool Sets: ES2500877 and ES517779.