



INSTALLATION GUIDE

CTS Turbo Audi B9 A4 2.0T Intake
CTS-IT-290



20630 Mufford Crescent, Unit #309
Langley, British Columbia V2Y 2V9

www.CTSTURBO.com

WHAT IS INCLUDED

1. Heat Shield
2. Gear clamps
3. Air filter
4. Silicone connector
5. Inlet pipe
6. Heatshield supports
7. Weather strips

**TOOLS REQUIRED**


1. T - 25 Torx
2. 7 mm, 8mm socket

NOTES

Vehicle used in this guide is a 2017 Audi A4. Always make sure the car is safe to work on. Do not work on a hot motor. We do not accept any liability for incorrect installation or damage during the install.

STEP 1

Remove the handle from the hood release by pushing in at the top of the handle


**STEP 2**

Unclip the cover from the top of the grille by pulling up and forward.




STEP 3

Unscrew the factory air duct

**STEP 4**

Remove the turbo inlet pipe by loosening the 8mm hose clamps



STEP 5

Remove airbox by pulling up.

**STEP 6**

Remove the two rubber grommets from the bottom of the factory airbox and set them aside.



STEP 7

Attach the two heatshield supports using a 7mm socket and a philips screwdriver


**STEP 8**

Attach the rubber grommets you set aside to the heatshield brackets.



STEP 9

Insert the heatshield in the position as shown


**STEP 10**

Attach the silicone coupler to the factory turbo inlet pipe.



STEP 11

Attach intake pipe to the silicone coupler using an 8mm hose clamp


**STEP 12**

Attach the air filter with the other 8mm hose clamp



STEP 13

install the weather stripping as shown


**STEP 14**

Fit the factory air duct back into place and fasten using the factory torx screws.




STEP 15

Attach the factory vacuum line to the inlet pipe

**STEP 16**

Reinstall the factory cover and handle



STEP 17

Stand back and admire your work. You are done!

