

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. Accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use and should be installed by a qualified automotive technician.

No Drill - Billet Licence Plate Mount

Check to make sure that you have all parts listed prior to installation. If anything is missing contact us immediately.
 802.893.7366

Parts List:

- (1) ball socket bracket top
- (1) ball socket bracket bottom
- (1) plate mount
- (2) 92196A539 - 18-8 S/S Socket Head Cap Screw 1/4"-20 x 7/8"
- (2) 92210A302 - 18-8 S/S Flat Head Sckt Cap Screw 10-32 x 1/2"
- (4) 92949A560 - 18-8 SS Button Head Socket Cap Screw 1/4"-28 x 3/8"

1. Remove the plastic cap covering the tow hook receptacle.
2. Screw the threaded ball socket into the tow hook receptacle. Note: If your kit came with a spacer, install it at this time.
3. Tighten the threaded ball mount using a socket.
4. Mount the ball socket bracket to the plate mount as shown below. Note: There are several different mounting holes based on plate location preference and options such as parking sensors.
5. Attach the ball socket/plate mount assembly to the threaded ball mount and tighten the 2 mounting screws leaving them loose enough so the ball socket can be adjusted.
6. Adjust the plate mount to the desired angle and tighten the mounting screws.
7. Install your licence plate and enjoy your new Rennline product.

