



SKODA FABIA 1.2 TSI 2015 – ON

DUMP VALVE & FITTING KIT



TOOLS NEEDED:

Hose clamp driver

Posi drive screwdriver


M6 Allen key

Hose clamp pliers

1. Using hose clamp pliers remove the clamp that connects the cold air feed to the airbox and also the airbox to the inlet hose as pictured below.



2. Now remove the inlet hose from the slam panel by pushing down on the retaining clips as pictured below.




3. Remove the pipe from your airbox to the cam cover breather.




4. Now by pulling upwards in a sharp movement, remove the airbox .


5. Unclip the wiring loom from your map sensor on your boost pipe. Then by prying the arrowed red tabs outwards, remove the sensor completely.




6. You can now unclip your boost hose by prying open the tabs on the coupler joining the throttle body .




7. Unclip the opposite end of the boost pipe by again prying open the tabs arrowed red, then remove the boost pipe from its position.



8. Insert the new Forge coupler into position by pushing until you hear it click.



9. You must now remove the OEM o-ring from the boost pipe and place in the new Forge Motorsport throttle body coupler.




10. Place the o-ring in the new coupler where arrowed below.




11. Now fit your coupler into position, again pushing until you hear a click. Then using a 6mm allen key, fit your MAP sensor and connect the wiring loom.




12. You must now remove the MAP sensor that's mounted in your inlet manifold. Again pry the clips apart while pulling on the sensor.



13. The boost source take off adaptor must now be placed in position on the manifold, push down again until you feel it click into position.



14. Now fit the sensor to the take off block using the posi screws provided and tighten with a posi drive screwdriver.




15. Fit the large silicon boost pipe into position and tighten the hose clamps with your hose clamp driver. Tighten the hose clamp at the small end first as this ensures the boost pipe is sat in the correct position .



16. Now fit the new Forge Motorsport dump valve into position and tighten the hose clamp that holds it in position.



17. Now connect the vacuum pipe supplied from the top of the dump to the boost take off block you fitted in section 14. Using the tie clips provided, fasten the vacuum tube to the coolant pipe pictured and arrowed white.



18. Now follow steps 1-4 in reverse order to reassemble your air box .

19. Your vehicle is now ready for a test drive .



Check out WWW.FORGEMOTORSPORT.CO.UK and
WWW.FORGEMOTORSPORT.COM

For a full range of performance products for your vehicle.

As always, with any questions or concerns about this product or anything else, please feel free to contact your local or preferred Forge Motorsport Dealer/ Installer, or you may contact us directly.

Forge Motorsport UK – (+44)1 452 380 999 / info@forgemotorsport.co.uk

Forge Motorsport US – (407)-447-5363 / sales@forgemotorsport.com



ENGINEERED FOR PERFORMANCE