

VW MK7 JACK PAD ADAPTER ADDENDUM

This document has been created to help our customers install the front Jack Pad Adapter onto the MK7. Let's take a look at how the MK7 differs from previous models:

1. The photo below shows the location of the front jack pad adapter, it is located behind the highlighted panel. Begin by removing the single T25 screw from the panel (circled in photo below).



2. We need to remove this panel in order to install the adapter. To do this, simply push in on the locking tabs (circled in photo below), while simultaneously sliding the panel toward the rear of the vehicle.



VW MK7 JACK PAD ADAPTER ADDENDUM

3. With the panel removed you can see the hole where the adapter is to be installed (circled in photo below). Completely remove the panel from the vehicle, then reinstall the T25 screw since it secures the wheel well liner in place. Repeat this process on the other side.



These instructions are provided as a courtesy by ECS Tuning

Proper service and repair procedures are vital to the safe, reliable operation of all motor vehicles as well as the personal safety of those performing the repairs. Standard safety procedures and precautions (including use of safety goggles and proper tools and equipment) should be followed at all times to eliminate the possibility of personal injury or improper service which could damage the vehicle or compromise its safety.

Although this material has been prepared with the intent to provide reliable information, no warranty (express or implied) is made as to its accuracy or completeness. Neither is any liability assumed for loss or damage resulting from reliance on this material. SPECIFICALLY, NO WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR ANY OTHER WARRANTY IS MADE OR TO BE IMPLIED WITH RESPECT TO THIS MATERIAL. In no event will ECS Tuning, Incorporated or its affiliates be liable for any damages, direct or indirect, consequential or compensatory, arising out of the use of this material.