

Weighted Shift Knob Installation Instructions



Thank you for purchasing your new ECS Tuning
Weighted Shift Knob we appreciate your business!

**Clean Engraving:**

- Our shift knobs are available for 5 and 6 speed applications.

Sleek and Durable Finish:

- Our shift knobs are constructed of billet aluminum and available in a black, red, clear or blue anodized finish.

Comfortable Grip:

- Our shift knobs are available in full billet or wrapped in suede or leather.

Seamless Install:



- The collar nut features a cavity which holds the ends of the shifter boot in place against the collar for a clean look.

Fully Customizable:

- The lower collar is interchangeable and is available in black, red, clear, or blue anodized finish.

Section 1: Removing the Stock Shift Knob & Boot

- Step #1**
- Pry up and remove any trim preventing you from removing the shifter boot.
 - Pry up and free the boot from the vehicle and pull it upward to reveal the base of the stock shift knob.
- Step #2**
- Remove the clamp securing the knob to the shifter.
- Step #3**
- Using a heat gun and flat head screwdriver, pry the plastic retaining clip free from the boot.
 - These retaining clips vary from model to model, but the procedure for removing them is the same regardless.
- Step #4**
- Pull the knob, boot, and trim straight up to remove from the shifter.



Section 2: Installing the New Shift Knob

- Step #1**
- Install the shift knob collar onto the new ECS Shift Knob.
 - Push the threaded end of the knob through the opening in the shifter boot until the boot is completely flipped inside out.
- Step #2**
- Slide the black collar nut over the shifter with the threaded side down.
 - Slide the knob over the shifter and make sure that the engraving on top is straight.
 - Apply threadlocker to the three set screws and install them in the knob to hold it onto the shifter.
- Step #3**
- Tuck the ends of the shifter boot into the collar nut, then screw it onto the bottom of the shift knob until snug to hold the boot in place for a clean look.
- Step #4**
- Reinstall the boot and any trim that you removed.

