ECSTUNING

Audi B8 A4/S4 Carbon Fiber Engine Bay Cover Installation Instructions - ES3570283/ES3570284





Thank you for purchasing your new ECS Tuning **Carbon Fiber Engine Bay Cover we appreciate your business!**





- Our engine bay cover kit
 - clips onto an A/C line and a brake line for a simple and clean installation.
- **Complete Kit**
 - Each kit includes two pipe clips, a stud and a grommet

Our engine bay cover uses a rubber grommet and stud to keep the cover in place preventing movement and vibration.

Proper service and repair procedures are vital to the safe, reliable operation of all motor vehicles as well as the personal safety of those performing the repairs. Standard safety procedures and precautions (including use of safety goggles and proper tools and equipment) should be followed at all times to eliminate the possibility of personal injury or improper service which could damage the vehicle or compromise its safety.

Section 1: Installing the Engine Bay Cover

- **Step #1** Install the rubber grommet into the hole in the side of the cover.
 - Install the larger pipe clip into the hole closest to the front of the cover.
 - Install the smaller pipe clip into the hole closest to the center of the cover.
- **Step #2** Install the provided stud into the front-most hole on the LH side of the chassis.
- **Step #3** Route the cover into place, ensuring that the stud slides into the grommet we installed.
- **Step #4** Pivot the cover downward, ensure that the smaller pipe clip pops on to the brake line and the larger clip pops onto the AC line.

Congratulations, your installation is complete!









1.800.924.5172