

VW MK6 GTI ABS Rear Diffuser Installation Instructions - ES4049681



Skill Level 1 - Easy Basic Skills Required













INSTALLATION NOTES

- **RH** refers to the *passenger side* of the vehicle.
- **LH** refers to the *driver side* of the vehicle.
- Always use the proper torque specifications.
- If applicable to this installation, torque specifications will be listed throughout the document and at the end as well.
- Please read all of these instructions and familiarize yourself with the complete process **BEFORE** you begin.

GENERAL PREPARATION AND SAFETY INFORMATION

ECS Tuning cares about your health and safety, please read the following safety information. This information pertains to automotive service in general, and while it may not pertain to every job you do, please remember and share these important safety tips.

- Park your car in a safe, well lit, level area.
- Shut the engine off and remove the key from the ignition switch.
- Make sure any remote start devices are properly disabled.
- **ALWAYS** wear safety glasses.
- Make sure the parking brake is applied until the vehicle is safely lifted and supported.
- Whether lifting a vehicle using an automotive lift or a hydraulic jack, be sure and utilize the factory specified lift points.
- Lifting a vehicle in an incorrect location can cause damage to the suspension/running gear.
- **ALWAYS** support the vehicle with jack stands.
- **ALWAYS** read and follow all safety information and warnings for the equipment you are using.



NEVER get underneath a vehicle that is supported only by a jack, and **ALWAYS** make sure that the vehicle is securely supported on jack stands.



REMOVING THE STOCK REAR VALANCE

Step 1:

T25 Torx

Remove the four fasteners (circled in RED) which secure the valance to the rear bumper.



Step 2:

Firmly pull the valance away from the bumper, starting on the sides and slowly working your way towards the center until it pops free.



Removing the stock rear valance will take a good bit of force. Place one hand on the rear bumper to brace it, then grip the valance at the first clip and firmly pull back until the clip pops free from the bumper. Repeat this process with each clip until the valance comes free.






INSTALLING THE NEW REAR DIFFUSER

Step 3:

5mm Hex (Allen), 13mm Wrench

Install the new mounting bracket onto the two factory mounting brackets as shown using the supplied hardware. Refer to the illustration below to ensure hardware is installed correctly.



Step 4:

Carefully lift the new diffuser into place and gently push inward to pop the mounting clips into the bumper, holding it in place.



It can be a little tricky to get the center clips on the diffuser to fully engage the bumper, we found that if you slide your hand inside the bumper and support it while your push the diffuser into place, it helps those clips pop into place a LOT easier.





INSTALLING THE NEW REAR DIFFUSER

Step 5:

5mm Hex (Allen)

Install the two mounting bolts (arrows) through the diffuser and into the mounting brackets as shown and tighten until snug.



Be careful not to over tighten the bolts. Over tightening the bolts can crack the diffuser.



Step 6:


T25 Torx

Make sure the sides of the diffuser are aligned with the curves of bumper then install the six supplied self-tapping screws (arrows).



The screws should only be tightened until they make contact plus an additional ¼ turn. Over tightening will cause the screws to strip.

Congratulations, your installation is complete!



Your Rear Diffuser Kit installation is complete!



These instructions are provided as a courtesy by ECS Tuning

Proper service and repair procedures are vital to the safe, reliable operation of all motor vehicles as well as the personal safety of those performing the repairs. Standard safety procedures and precautions (including use of safety goggles and proper tools and equipment) should be followed at all times to eliminate the possibility of personal injury or improper service which could damage the vehicle or compromise its safety.

Although this material has been prepared with the intent to provide reliable information, no warranty (express or implied) is made as to its accuracy or completeness. Neither is any liability assumed for loss or damage resulting from reliance on this material. SPECIFICALLY, NO WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR ANY OTHER WARRANTY IS MADE OR TO BE IMPLIED WITH RESPECT TO THIS MATERIAL. In no event will ECS Tuning, Incorporated or its affiliates be liable for any damages, direct or indirect, consequential or compensatory, arising out of the use of this material.