

ExactFit - Magnetic Phone Mount

VW MK6 GOLF/GTI

READ BEFORE INSTALLATION

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.



Part List:

- (1) P/N - PM01
 - Aluminum Ball
 - Magnetic Pad Assembly
 - Steel pads
- (1) Thread-Locking Alloy Button Head Socket Cap Screw - 10/32 x .5" - MC92360A248

1. Install the aluminum ball onto the metal bracket as shown using the supplied screw.
2. Pry up the radio trim panel with a plastic trim removal tool. (Photo 1)
3. Locate the 2 Torx T20 screws to the right of the radio and remove them. (Photo 2)
4. Put Phone mount in place and reinstall screws. Make sure to push phone mount towards passenger side of dash as much as possible before tightening screws.. (Photo 3)
5. Reinstall radio trim panel. (Photo 4)

Photo 1



Photo 2



Photo 3



Photo 4

