

**ExactFit - Magnetic Phone Mount**

VW MK5 GOLF/GTI

**READ BEFORE INSTALLATION**

The use of any Rennline product is the sole responsibility of the end user. Rennline Inc. accepts no responsibility for warranty voids or damage resulting from the use of these products. Due to the varying location of wiring harnesses and other components, carefully inspect any area prior to drilling. All Rennline products are intended for off road use only and should be installed by a qualified automotive technician.



**Part List:**

- (1) Mounting Bracket - P/N - PM15
- (1) P/N - PM01
  - Aluminum Ball
  - Magnetic Pad Assembly
  - Steel pads
- (1) Thread-Locking Alloy Button Head Socket Cap Screw - 10/32 x .5" - MC92360A248

1. Install the aluminum ball onto the metal bracket as shown using the supplied screw.
2. Pry the trim panel up from the top of the dash with a plastic trim removal tool. (Photo 1)
3. Locate the Torx T20 screw at the very front of the panel and remove it. (Photo 2)
4. Carefully pull the front of the panel towards you while lifting up. (Photo 3)
5. Locate the two Torx T20 screws holding the vent trim and remove them. (Photo 4)
6. There are 3 clips on the forward part of the vent panel. Use your trim tool and release these clips. (Photo 5)
7. Pull the trim panel up to remove the vent panel. (photo 6)
8. Remove the two Torx T20 screws from the top of the radio trim. (Photo 7)
9. Starting at the top of one side, gently pull the trim panel forward. Slide your trim removal tool between the panel and dash and gently pry the panel away from the dash. (Photo 8)
10. Remove the two Torx T20 screws from the side of the radio and slide your trim tool between the radio and the dash foam. Insert the Exact-Fit phone mount between the trim tool and the dash foam. Tighten the two Torx T20 screws. (Photo 9)
11. Reinstall all the plastic trim and screws in reverse order of dissassembly.
10. Attach the phone to your mount.
11. Enjoy your new Rennline product.

Photo 1



Photo 2



Photo 3



Photo 4



Photo 5



Photo 6



Photo 7



Photo 8



Photo 9



Photo 10

