

SIDSKIRT INSTALL

Hardware Includes:
24 x Self Tapper Screws
* 12 on each side



Install shall be made entirely at your own risk. We shall not be liable for any damage which may result from the Installation.

1. Use Car Jacks to Hold Sideskirt

Place sideskirt under sideskirt panel and use car jacks to secure it in place to your desired fitment. We will use these jacks as a guide so when you start drilling, the side skirts will be immobile due to the jacks pinning it against the car.

In the picture below we used 3 car jacks to immobilize the movement of the sideskirt.



2. Check Secureness

vDouble Check to make sure the sideskirt is pinned against sideskirt panel and is at your desired look.



3. Begin Drilling

Drill through pre-existing holes using self taper screws into the bumper until the it is secured tightly onto the bumper.
Drill more holes if needed

Hardware used:
12 x Taper Screws for one side of car



4. Measure the Sideskirt After 1st Install

Once the sideskirt on one side of the car is done use a measuring tape or ruler to check how much the back and the front stick out past the sideskirt under panel.

Write down the measurement

In the picture, we used car jacks to loosen the tightness of sideskirt onto the under panel in order to properly place the sideskirt to the new measurement



5. Begin Install of NEW Sideskirt

When the new sideskirt is being placed onto other side of the car. Use measuring to tape or ruler to measure how far the sideskirt on the other side sticks out to get a parallel look.

PLEASE MAKE SURE SIDESKIRT IS MEASURED AND PLACED TO THE EXACT SAME MEASUREMENTS AS OTHER SIDE BEFORE DRILLING



6. REPEAT PROCESS - FROM STEP 2