



Audi B9 Upgraded Intake Air Scoop Installation Overview



**Thank you for purchasing your new ECS Tuning
Upgraded Intake Air Scoop, we appreciate your business!**



Features:

- Slotted mounting holes for easy installation.



Benefits:

- Wider, longer scoop serves as a better/larger guide for incoming air.
- Completely hidden installation.
- Perfectly compliments our ECS Intake Systems.

ECS Difficulty Gauge



1 - Easy

2 - Moderate




Pro - 4

Advanced - 3

Proper service and repair procedures are vital to the safe, reliable operation of all motor vehicles as well as the personal safety of those performing the repairs. Standard safety procedures and precautions (including use of safety goggles and proper tools and equipment) should be followed at all times to eliminate the possibility of personal injury or improper service which could damage the vehicle or compromise its safety.

Section 1: Removing the Factory Intake Air Scoop



- Step #1**
- Look along the back edge of the hood release lever to locate the release button.
 - Push in on the button with your finger, then pull the hood release lever off.
- Step #2**
- Remove the radiator shroud by pulling up on the front edge to unclip it from the grille, then pull it forward to slide it out of the core support.
- Step #3**
- Remove the two intake air scoop screws.
 - If you have a factory intake system, these will be T25 screws.
 - If you have an ECS intake system, these will be 4mm allen screws, and you will need to remove the air box lid (if equipped).
- Step #4**
- Pull the air scoop out of the core support and remove it.



You are now ready to install your new Upgraded Intake Air Scoop!

Section 2: Installing the New Upgraded Intake Air Scoop

- Step #1**
- Insert the front edge of the new upgraded intake air scoop into the recess behind the grille, be sure to align the air scoop as high as possible inside the recess as shown.
 - There are small tabs inside the recess which need to be located **UNDERNEATH** the scoop for proper fitment (not shown).
 - Check the gap between the air scoop and the top of the recess, it should be approximately 10mm ($\frac{3}{8}$ ").
- Step #2**
- Reinstall the two intake air scoop screws.
- Step #3**
- Reinstall the radiator shroud and the hood release lever.



Your installation is now complete!